

REALCARE® BABY DIAGNOSTIC TEST

You have RealCare® Baby if your electronics box looks like the one shown below:



Items required for test:

- RealCare® Baby
- Four new C size batteries
- One ID
- One large paper clip
- Both diapers (one with blue colored patch and one with white colored patch)
- A feeding device (bottle or breastfeeding device)
- Battery cover key
- Control unit with new 9-volt battery

Perform the following:

1. Remove the t-shirt and diaper.
2. Install the batteries. When batteries are installed correctly, you will hear a beep. If a beep is not heard, try removing the batteries and installing again. (You should wait 15 seconds before installing the batteries.) Ensure that the battery removal ribbon is placed properly. This will prevent it from getting caught in the lock and between the battery and battery contacts.
3. Install and lock the battery cover.
NOTE: The battery cover must be on to prevent batteries from losing contact.
4. Place Baby in a sitting position with the battery compartment facing you.
5. Turn on the control unit by pressing the ON/OFF button.
6. When the display on the control unit reads MAIN MENU <Auto Program>, press the PREVIOUS SCREEN and MAIN MENU buttons at the same time. When you let go of these two buttons, the screen should read "Touch to Baby Contact Point."
7. Touch the control unit to the contact point on Baby's back. The message "Touch Any ID to Start Baby" will appear. DO NOT TOUCH THE ID! Set the control unit to the side.

Proceed with the following 11 tests:

Baby should **beep** and the low battery light should flash for each test to indicate Baby is passing. *(If any of the tests do not pass, you can proceed to the next test by momentarily touching an ID to Baby's back. You will hear one beep. Do not hold the ID longer than a moment because if you hear more than one beep, you have skipped 2 or more tests).*

1. HEAD SUPPORT TEST

- a. Allow Baby's head to fall all the way back.
- b. One **beep** should be heard.

2. ROUGH-HANDLING TEST

a. Trigger the rough-handling sensor by hitting Baby on its back below the battery compartment. One **beep** should be heard.

3. EMERGENCY START/STOP BUTTON TEST

a. Lightly press the Emergency Start/Stop button with a large paper clip.
b. One **beep** should be heard.

4. BLUE DIAPER TEST

a. Put the diaper with the *blue* patch up to the hook & loop fastener on Baby's back.
b. One **beep** should be heard.

5. WHITE DIAPER TEST

a. Put the diaper with the *white* patch up to the hook & loop fastener on Baby's back.
b. One **beep** should be heard.

6. FEEDING SENSOR TEST

a. Place the bottle or breastfeeding device against Baby's mouth.
b. You should hear a continuous **beeping**.

7. 1st POSITION TEST

a. Tilt and hold Baby on its *right* side.
b. **Beeping** should **STOP**. Continue holding on its *right* side.

8. 2nd POSITION TEST

a. Touch an ID to the contact point on Baby's back.
b. You should hear a continuous **beeping** sound.
c. Tilt and hold Baby on its *left* side.
d. **Beeping** should **STOP**. Continue holding on its *left* side.

9. 3rd POSITION TEST

a. Touch an ID to the contact point. Baby will **beep** once.
b. Tilt Baby on its *right* side and Baby will start **beeping**.
c. Tilt and hold Baby on its *left* side.
d. **Beeping** should **STOP**. Continue holding on its *left* side.

10. 4th POSITION TEST

a. Touch an ID to the contact point.
b. You should hear a continuous **beeping** sound.
c. Tilt Baby on its *right* side.
d. **Beeping** should **STOP**. Continue holding on its *right* side.

11. SOUNDS TEST

a. Touch an ID to the contact point.
b. You should hear a loud **beep** and Baby should **cry** for about 5 seconds.

Baby is working correctly if it has passed each step of the test. If Baby has failed, try once more with a new set of batteries.